

Bending Iron No. 703921

1 Positioning of the device

- The device housing enables individual mounting (through 4 mounting points) onto a wooden block or similar or directly on the working bench. Be aware the surface temperature of the device during operation can reach 180 °C. Place the device and operate the device with a special concern for both personal safety and safety of surrounding environment.

2 Operation

- 2 Connect the device to 220 V mains only, use the supplied cord, be sure the socket used is correctly protected through grounding.

3 Setting the desired temperature

- Set the desired operational temperature on the mechanical switch of the front panel. (Typically, the operational temperature should be higher than 160 °C and lower than 200 °C, depending much on the structure of the wood). The device will heat up automatically and hold the temperature within +/- few °C. The actual temperature is shown on the display of the front panel.

4 Maintenance

- Any maintenance or repairs should be performed by qualified person only.

5 SAFETY INSTRUCTION

1. Place and operate the device in a safe place, respecting a high surface temperature.
2. The device remains hot a long time after its operation has been finished, do not leave unattended.
3. Use personal safety means (gloves) while operating to protect your hands.
4. Any repairs should be maintained by a qualified electro-maintenance staff.

The devices meet the conformity requirements of the European Union. 

 **DICTUM**

DICTUM GmbH – Gottlieb-Daimler Str. 3 D - 94447 Plattling Germany
www.dictum.com info@dictum.com